




SUPER DUTY AIR RATCHET WRENCH

(3/8" DRIVE OR 1/2" DRIVE)



INDEX NO.	DESCRIPTION	Q'TY	INDEX NO.	DESCRIPTION	Q'TY
01	PLUG	1	24-1	EXHAUST DEFLECTOR	1
02	O-RING	1	25	CLAMP NUT	1
03	THROTTLE VALVE SPRING	1	26	RATCHET HOUSING	1
04	VALVE	1	27	NEEDLE BEARING	1
05	VALVE STEM	1	28	CRANK SHAFT	1
06	VALVE BUSHING	1	29	DRIVE BUSHING	1
07	INLET BUSHING	1	30	YOKE	1
08	THROTTLE LEVER	1	31	WASHER	1
09	SPRING PIN	1	32A	REVERSE BUTTON ASSY	1
10	HANDLE	1	33	PAWL PIVOT	1
10-1	EXHAUST DEFLECTOR SEAL	2	34 (3/8")	ANVIL ASSY	1
11	BEARING CAP	1	35	SPRING	1
12	BALL BEARING	1	36	SPRING CAP	1
13	REAR END PLATE	1	37	PAWL	1
14	ROTOR	1	38	FRICTION SPRING	2
15	BLADE	4	39	STEEL BALL	2
16	CYLINDER ASSY	1	40 (3/8")	THRUST WASHER	1
17	FRONT END PLATE	1	41 (3/8")	RETAINING RING	1
18	BALL BEARING	1	OPTION		
19	WASHER	1	32B	REVERSE BUTTON	1
20	INTERNAL GEAR	1	34 (1/2")	ANVIL ASSY	1
21	PLANET GEAR	3	40 (1/2")	THRUST WASHER	1
23	GEAR PLATE ASSY	1	41 (1/2")	RETAINING RING	1
24	BUSHING	1			